

CONTENTS

Introduction	2	Steering Rods and Ball Joints	122
Section I. General Data		Idler Arm Bracket	122
Specifications	3	Section VI. Brakes	
Main Adjustment and Check Data	5	Trouble Shooting	124
Fuels, Lubricants and Fluids	5	Checks and Adjustment	126
Section II. Engine		Clutch and Brake Pedal Bracket	130
Trouble Shooting	8	Vacuum Booster	131
Engine Removal and Installation	11	Brake Master Cylinder	131
Engine Disassembly	12	Front Brakes	132
Engine Assembly	14	Rear Brakes	134
Engine Stand Tests	17	Rear Brake Pressure Regulator	136
Engine Checkover on Car	17	Parking Brake	138
Cylinder Block	17	Section VII. Electrical Equipment	
Pistons and Connecting Rods	19	General	138
Crankshaft and Flywheel	23	Storage Battery	140
Cylinder Head and Valve Gear	25	Alternator	142
Camshaft and Drive	29	Voltage Regulator	147
Cooling System	32	Battery No-Charge Warning Lamp Relay	150
Lubricating System	35	Starter	150
Crankcase Breathing System	38	Ignition System	155
Fuel System	39	Lighting and Light Signalling System	160
Exhaust System	52	Horns	164
Section III. Power Train		Windshield Wiper	164
Clutch	53	Headlight Wiper	167
Gearbox	59	Heater Motor	167
Transfer Case	70	Instruments	168
Propeller Shaft Drive	77	Section VIII. Body	
Rear Axle	81	Trouble Shooting	173
Front Axle	95	Body and Its Elements	174
Front Wheel Drive	97	Body Paint Coating	178
Section IV. Running Gear		Anticorrosive Treatment of Body	179
Trouble Shooting	100	Doors	183
Front Suspension	102	Hood, Bumpers	186
Rear Suspension	110	Window Glasses, Windshield and Headlight	
Shock Absorbers	112	Washers	187
Section V. Steering Gear		Instrument Panel	189
Trouble Shooting	115	Seats	190
Inspection, Checks and Adjustment	117	Heater	190
Steering Mechanism	118		